




SCHEMA CAVO SERIALE UAP / PC

LATO CASSA UAP

LATO PC



3_{TX}


4_{RX}

6_{GND}

2_{RX}

3_{TX}

5_{GND}



PIN 1

